

## **INSTALLATION INSTRUCTIONS**

BEFORE INSTALLING OR ADJUSTING THIS PRODUCT,
PLEASE READ THESE INSTRUCTIONS CAREFULLY.
PLEASE KEEP THIS GUIDE FOR FUTURE REFERENCE

# FIELD TERMINATION PLUG STP C6A RIGHT ANGLE

#### 1.0 Scope

This document provides installation instructions for Molex Field terminable plug.

## 2.0 Product Description


FIELD TERMINATION PLUG STP C6A RIGHT ANGLE

#### 3.0 Procedure

**Tools required:** Plier, cable strippers, wire clippers, and screwdriver.


#### Step 1

• Insert cable through cable gland. Strip off cable jacket as shown, fold back the drain wire. Fan out all four twisted pairs, cut the conductors as shown.



#### Step 2

• Fan out all four twisted pairs, following the color-coding label and allocate each conductor into proper slot on wiring cap. Trim the ends of conductors.




	JACK PIN DESIGNATIONS	1 2 3 6 4 5 7 8	TIA / EIA T568A	T568B	INDUSTRIAL
			White/Green Green	White/Orange Orange	Yellow Orange
			White/Orange Orange	White/Green Green	White Blue
			Blue White/Blue	Blue White/Blue	
			White/Brown Brown	White/Brown Brown	

ENGINEERING RECORD	SAP NO: <b>187000561</b>	Doc No: <b>187000561</b>	Doc part: AS	DEV/ A
NO: <b>670225</b>	http://www.molexces.com			REV- A


#### Step 3

• Remove the wiring label before place wiring cap on plug.




## Step 4

• Place the wiring cap onto plug, use plier to clamp wiring cap until it completely snap-in to effect the connection.




### Step 5

• Close plug cover, make sure the drain wire is in proper contact with grounding clip on plug. Select the desired cable exit, bend the jacket-off cable, and allocate the Angle clamp on plug to create the cable exit direction, close the angle clamp and screw on the cable gland to complete the installation.



#### Unload the cable

 Release the cable gland, open the Angle clamp, remove the Angle clamp and Open plug cover. Using flat screwdriver pry gently on plug cover one end first and the other end subsequently to open it. As shown below.



ER NO : **670225** SAP NO : **187000561** Doc No: **187000561** Doc part: **AS** REV-A

MPN/FMT-042 (2019/DEC/23 REV-03).

SHEET No. **2** of **2**