

# **PLUG FIELD TERMINATION C6 UTP**

## 1.0 Scope

This document provides Installation Instructions for Molex C6 Field terminable Plug.


#### 2.0 Product Description

FIELD TERMINATION PLUG C6 UTP.

### 3.0 Procedure


**Tools required:** Plier, cable strippers, wire clippers, and screwdriver. **<u>Step 1</u>** 

• Insert cable through cable gland. Strip off cable jacket for 30mm(1.2"), Fan out all four twisted pairs, cut the conductors as shown.



#### Step 2


• Following the color-coding label and allocate each conductor into proper slot on wiring cap. Trim the ends of conductors.



		TIA / EIA T568A	TIA / EIA T568B	INDUSTRIAL
JACK PIN DESIGNATIONS	1 2 3 6 4 5 7 8	White/Green Green	White/Orange Orange	Yellow Orange
		White/Orange Orange	White/Green Green	White Blue
		Blue White/Blue	Blue White/Blue	
		White/Brown Brown	White/Brown Brown	

#### Step 3


• Remove the wiring label before place wiring cap on plug.



ENGINEERING RECORD	SAP NO : 187000570	Doc No: <b>187000570</b>	Doc part: AS			
NO : <b>724900</b>	http://www.molexces.com			REV- <b>A</b>		
MPN/FMT-042 (2019/DEC/23 REV-03).						
THIS INFORMATION IS CORRECT AS AT THE TIME OF PUBLICATION. SPECIFICATION ARE SUBJECT TO CHANGE. SHEET No. 1 of 2						


## Step 4

• Place the wiring cap onto plug, use plier to clamp wiring cap until it completely snap-in to effect the connection.




## <u>Step 5</u>

• Close plug cover, make sure the drain wire is in proper contact with grounding clip on plug. Place back the latch. Rotate the cable gland to fasten and complete the installation.



## Unload the cable

• Release the cable gland and Open plug cover. Using flat screwdriver pry gently on plug cover one end first and the other end subsequently to open it. As shown below.



ER NO : <b>724900</b>	SAP NO : 187000570	Doc No: <b>187000570</b>	Doc part: AS	REV- <b>A</b>
MPN/FMT-042 (2019/DEC/23 REV-03).			SHEET No. <b>2</b> of <b>2</b>	